

SINOX

SINOX TRÆFRONT TIL BEOSOUND STAGE™

MONTERING

- OBS: Løft forsigtigt i højttalerfronten, da lamellerne kan trykkes løse.
- Fjern stoffronten fra Beosound soundbar.
(Benyt vejledningen og værktøjet, der fulgte med din Beosound Stage)
- Læg træfronten med forsiden nedad på en jævn og ren overflade.
- Fjern de hvide beskyttere på velcroen.
- Behold begge velcrostykker sammen på fronten.
- Monter fronten, så velcroen klæbes direkte mod Beosound soundbar.
- Lad den sidde i minimum 30 minutter, før du forsøger at afmontere den igen.

Træ er et naturprodukt. Dvs. ingen er ens. Du bedes behandle dette med omhu, da træ kan knække, misfarves og ridses.

En løs lamel kan pålimes igen, hvis de mod forventning rives løs.
Træet kan efterbehandles med olier – med og uden farve.
Misfarvninger kan i nogle tilfælde fjernes med fint sandpapir eller "rensesvampe".

God fornøjelse!

SINOX WOOD PANEL FOR BEOSOUND STAGE™

ASSEMBLY

- NOTE: Carefully lift the speaker front, as the slats can be pressed loose.
- Remove the fabric front from the Beosound soundbar.
(Use the instructions and tool that came with your Beosound Stage)
- Place the wooden front face down on a flat and clean surface.
- Remove the white protectors from the Velcro.
- Keep both Velcro pieces together on the front.
- Mount the front so that the Velcro sticks directly to the Beosound soundbar.
- Let it sit for a minimum of 30 minutes before trying to disassemble it again.

Wood is a natural product. Not two are alike. Please treat with care as wood can crack, discolour and become scratched.

A loose slat can be glued on again if it tears loose.
The wood can be finished with oils – with or without colour.
Discolourations can in some cases be removed with fine sandpaper or "cleaning sponges".

Enjoy!